

# Fixing guidance for Siderise CLS system using PP1 or IH3

## Before using

Test the product to determine its suitability for each specific application. Please note we have no control over the method of application, environment or parent surface bonding conditions, therefore, the user assumes all responsibility, risk and liability in connection with the use and application of this product.

## Clean Parent Surface

All hangers must be applied to a clean, dry, uncoated surface that is completely free of contaminants such as dirt, dust, film, grease, oil, paint or other protective coatings, rust salt etc. Concrete should be wire brushed to remove all laitance.

## Apply Adhesive to the Hanger

Prepare only one hanger at a time. Apply a daub of adhesive (about the size of a walnut) on the perforated base plate with a putty knife or cartridge gun. For best results with hangers, use Siderise AD-PIN premium brand adhesive in 300ml cartridges. We cannot consider any claim of product failure resulting from the application of hangers with other brands of adhesive.

## Select Hanger Locations

Press hanger firmly into place with a twisting motion to assume an even spread of adhesive. Properly installed, the adhesive should be between 1mm to 2mm thick and should protrude through the perforations and beyond the edges of the base plate.





Do not install when ambient temperature is below 4.5°C or higher than 35°C. Best results are generally obtained when ambient temperature is between 15°C and 29°C. For application temperatures outside these ranges please consult a specialist adhesive supplier.

Hanger spacing should not exceed 600mm on centre, see CLS data sheet for guidance on number of fixings required. Under high temperature / high humidity conditions, remove the hanger from parent surface for a few seconds after initial application to allow adhesive to be exposed to air. Then reapply with the same twisting motion.

## Allow Adhesive to cure thoroughly

Allow adhesive to cure thoroughly before installing insulation, (minimum time 24-48 hrs), drying times vary, therefore, user should ventilate the application area to remove entrapped adhesive solvent vapours and to shorten the drying time.

High humidity conditions or ambient temperature under 7.2°C may require additional curing time. Before installing insulation make certain that the curing process is complete and that the hangers will develop full strength.



### Offer up and Impale CLS System





When considering the order of application of the CLS System, the following shows a typical order of treatment.

Treatment would be started to the top left of the treatment area, with all sheets orientated to suit the proposed layout. The first sheet should be offered up to the hangers, then impaled on to the Insulation Hanger spikes, the second sheet should be positioned directly below, tightly abutting the first sheet, this should be repeated until the bottom of the treatment area, completing the 1st row.

The second row would again start at the top of the treatment area, to the right of the 1st sheet, this should be continued as above, further rows would be fitted until complete treatment area is covered.

### Secure with self-locking washers

After installing insulation, slide on self-locking washer (Dome side out) to pin without compressing insulation. Trim off surplus pin if necessary. Hanger loading should not exceed 3lbs (1.36 kg) per hanger.



*For any queries relating to these guidelines, including any 'Project Specific' queries, please contact our Technical Team.*

# Further information

## Technical support

For further information please contact our technical team at the address below.

## Available CPD's

Contact Siderise for further information on our CPDs:

- Siderise Acoustic Products for Commercial Interiors - Architect Edition
- Siderise Acoustic Products and Performance with 1/3<sup>rd</sup> Octave Data – Acoustic Consultants Edition

## Sales & Technical

### SALES SUPPORT

[Internal Sales Team](#)

T: +44(0)1473 827695

E: [sales.sspl@siderise.com](mailto:sales.sspl@siderise.com)

[Technical Team](#)

T: +44(0)1473 827695

E: [technical.sspl@siderise.com](mailto:technical.sspl@siderise.com)

BY  
YOUR  
SIDE



SIDERISE GROUP  
Lady Lane Industrial Estate,  
Hadleigh, Suffolk IP7 6BQ  
T: +44(0)1473 827695  
F: +44(0)1473 827179  
E: [sales.sspl@siderise.com](mailto:sales.sspl@siderise.com)  
W: [www.siderise.com](http://www.siderise.com)