

<p><b>1</b> Siderise Foil Tape RFT120/45, suitable non-combustible fixings with a washer 10 –15mm in diameter and spiral screws.</p>	<p><b>2</b> <b>Cutting on site</b> – tools required: marker, tape measure, knife and saw.</p>	<p><b>3</b> <b>Cutting on site</b> – measure the cover area size and mark on the foil facing your cut line.</p>	<p><b>4</b> <b>Cutting on site</b> – Use a sharp knife to cut through the foil and net facings.</p>	<p><b>5</b> <b>Cutting on site</b> – Cut the stonewool with a saw, being careful not to rip the foil facing.</p>
<p><b>6</b> Line up the board against the back of the façade checking the full area is covered.</p>	<p><b>7</b> Use non-combustible fixings with a washer 10-15mm in diameter to fix the board to the façade; 6-7 number per m<sup>2</sup>.</p>	<p><b>8</b> Using Siderise Foil Tape RFT120/45, tape any exposed screw heads and washers.</p>	<p><b>9</b> Siderise Firestop can now be installed between the structure and the protected spandrel.</p>	<p><b>10</b> <b>Installing Barrier</b> – Take the CW-FS unit and apply manual compression to install it into the cavity.</p>
<p><b>11</b> Fix the CW-FS (width as per listing) covering the back of the mullion and overlapping the first board under the firestop using spiral screws.</p>	<p><b>12</b> Using the Siderise Foil Tape RFT120/45, tape the exposed stone wool edges and screw heads to the fire boards.</p>	<p>SCAN / CLICK HERE FOR</p> <p>FURTHER INSTRUCTIONS</p>		