
















 <p>Cut line Compression allowance Size of void</p>		
<p>1 You need: Siderise® Fixing Brackets, Siderise® Foil Tape RFT 120/45, suitable non-combustible mechanical fixings appropriate to substrate, supplied by contractor.</p>	<p>2 Cutting on site - tools required: marker, tape measure, knife and saw.</p>	<p>3 Cutting on site - measure and mark the sheet: size of the void plus compression allowance stated in the product datasheet.</p>	<p>4 Cutting on site - Cut in the direction that is marked on the foil face of the PC-FS / PC-CB sheets.</p>	<p>5 Cutting on site - Use a sharp knife to cut through the foil facings on both sides.</p>
				
<p>6 Cutting on site - Cut the stone wool with a saw, being careful not to rip the foil facing.</p>	<p>7 Inserting brackets - Impale a fixing bracket mid thickness into PC-FS / PC-CB strip. A sharp knife can be inserted first to make it easier. Fixing brackets are impaled at nominal 600mm fixing centres, i.e. 300mm from each end.</p>	<p>8 Inserting Brackets - Using personal protection equipment (e.g. gloves) fold the bracket as shown.</p>	<p>9 Inserting Brackets - Penetration of bracket is 75% of the width of the cut strip (e.g. if the cut strip is 100mm wide, bracket penetration is 75mm).</p>	<p>10 Installing Barrier - Take the PC-FS / PC-CB unit and apply manual compression to install it into the cavity.</p>
				
<p>11 Installing Barrier - Take the PC-FS / PC-CB unit and apply manual compression to install it into the cavity.</p>	<p>12 Installing Barrier - Secure non-combustible fixings in accordance with manufacturer's instructions, noting edge distance requirements.</p>	<p>13 Installing Barrier - Secure non-combustible fixings in accordance with manufacturer's instructions, noting edge distance requirements.</p>	<p>14 Installing Barrier - When cut strips are inserted into the cavity, the fixing brackets are simply located over the support structure.</p>	<p>15 Installing Barrier - Apply manual pressure.</p>
				<p>SCAN / CLICK HERE FOR</p>  <p>FURTHER INSTRUCTIONS</p>
<p>16 Installing Barrier - Secure non-combustible fixings in accordance with manufacturer's instructions, noting edge distance requirements.</p>	<p>17 Install tightly abutted ensuring that there are no gaps between PC-FS / PC-CB strip sections.</p>	<p>18 Install tightly abutted ensuring that there are no gaps between PC-FS / PC-CB strip sections.</p>	<p>19 Use Siderise RFT 120/45 foil tape to seal abutted joints of PC-FS / PC-CB: top face in horizontal applications, both faces in vertical applications. Corner joints should be mitred unless corner detail has no movement/locked in place.</p>	